

Bose loudspeaker EQ list

EQ Version: V1.2.00.G

EQ List
80 Hz HPF
60 Hz HPF
50 Hz HPF
40 Hz HPF
DS16S
DS16SE
DS16F
DS16FP *
DS100SE
DS100F
DS100FP *
M32
M32SE
102F
M8
M16
M16P *
FS3 I
FS3 II
FS3 II P *
FS3 55Hz HPF
FS3 80Hz HPF
FS3 B
302A
FS 203
FS 360P
402 II
502A
MA12
MA12 EX

*This equalization is intended for use when loudspeaker is pendant-mounted only.